

335

Adjustment Manual

This Adjustment Manual is valid for machines from the following serial numbers onwards:

# 2734226 ---

The reprinting, copying or translation of PFAFF Service Manuals, whether in whole or in part, is only permitted with our previous authorization and with written reference to the source.
PFAFF Industrie Maschinen AG
Postfach 3020 D-67653 Kaiserslautern
Königstr. <b>154</b> D- <b>67655</b> Kaiserslautern

	Contents	Page
13	Adjustment	5
13.01	Notes on adjustment	5
13.02	Tools, gauges and other accessories for adjusting	5
13.03	Abbreviations	5
13.04	Explanation of the symbols	5
13.01	Adjusting the basic machine	6
13.04.01	Lateral positioning of the feed dog	6
13.04.02	Lengthwise positioning of the feed dog	7
13.04.03	Height of the bottom feed dog (only on machines with lifting phase – P-version)	8
13.04.04	Centering the needle in the needle hole	9
13.04.05	Pre-adjusting the needle height	10
13.04.06	Driving motion of the top and bottom feed dogs	11
13.04.07	Lifting motion of the bottom feed dog (only on machines with lifting phase – P-vers	sion) 12
13.04.08	Needle rise, hook-to-needle clearance and needle height	13
13.04.09	Vibrating presser lift	14
13.04.10	Vibrating presser feeding motion	15
13.04.11	Needle thread tension release	16
13.04.12	Thread check spring	17
13.04.13	Bobbin winder	18
13.04.14	Regulating the pressure on the presser foot	19
13.05	Adjusting the thread trimmer -900/52	20
13.05.01	Preadjusting the control cam	20
13.05.02	Tripping lever height	21
13.05.03	Control pin	22
13.05.04	Engaging solenoid	23
13.05.05	Control pin height	24
13.05.06	Front position of thread catcher	25
13.05.07	Lateral position of thread catcher	26
13.05.08	Control cam (final adjustment)	27
13.05.09	Knife	28
13.05.10	Needle thread tension release	29
13.05.11	Cutting test	30

# Index

	ContentsP	age
13.06	Parameter settings (only on machines with Quick-EcoDrive and control unit P40ED)	31
13.06.01	Parameter list	31
14	Circuit diagrams	32



Please observe all notes from Chapter 1 Safety of the instruction manual! In particular care must be taken to see that all protective devices are refitted properly after adjustment, see Chapter 1.06 Danger warnings of the instruction manual!



If not otherwise stated, the machine must be disconnected from the electrical power supply. Danger of injury due to unintentional starting of the machine!

### 13.01 Notes on adjustment

All following adjustments are based on a fully assembled machine and may only be carried out by expert staff trained for this purpose.

Machine covers, which have to be removed and replaced to carry out checks and adjustments, are not mentioned in the text.

The order of the following chapters corresponds to the most logical work sequence for machines which have to be completely adjusted. If only specific individual work steps are carried out, both the preceding and following chapters must be observed.

Screws, nuts indicated in brackets () are fastenings for machine parts, which must be loosened before adjustment and tightened again afterwards.

### 13.02 Tools, gauges and other accessories for adjusting

- Screwdrivers with blade width from 2 to 10 mm
- Spanners (wrenches) with jaw width from 7 to 14 mm
- Allan keys from 2 to 6 mm
- Metal rule (part No. 08-880 218-00)
- Needle-rise gauge (part No. 61-111 600-01)
- Gauge, (top feed stroke **7 mm**) (Part No. 61-111 633-61)
- Screw clamp (part No. 61-111 600-35)

#### 13.03 Abbreviations

t.d.c. = top dead centre b.d.c. = bottom dead centre

#### 13.04 Explanation of the symbols

In this adjustment manual, symbols emphasize operations to be carried out or important information. The symbols used have the following meaning:



Note, information




Service, repair, adjustment, maintenance (work to be carried out by qualified staff only)

## 13.01 Adjusting the basic machine

13.04.01 Lateral positioning of the feed dog

### Requirement

The clearances from the left and right of the bottom feed dog 1 to the needle plate cutout must be the same size.






• Move the bottom feed dog 1 (screws 2) in accordance with the requirement.

## 13.04.02 Lengthwise positioning of the feed dog

### Requirement

With the stitch length set at its longest the clearances behind and in front of the bottom feed dog 4 to the needle plate cutout must be the same.






- Set the longest stitch length.
- Move the clamp piece 1 (screws 2) as far to the left as possible on the clamp surface 3
  of the rock shaft. The left screw must still be on the clamp surface.
- Position feed dog 4 (screws 5) according to requirement.

13.04.03 Height of the bottom feed dog (only on machines with lifting phase – P-version)

### Requirement

When the stitch length is set at "0", in its highest position the bottom feed dog 4 should be 0.8 - 1.1 mm above the top edge of the needle plate.





- Set the stitch length at "0".
- Adjust eccentric 1 and 2 (screws 3) in accordance with the requirement.




The bottom feed dog 4 should not touch cloth plate 5.

### 13.04.04 Centering the needle in the needle hole

#### Requirement

With the stitch length set at "0" the needle must enter the needle hole exactly in the middle.





- Unscrew the vibrating presser foot 1 and the presser foot 2.
- Set the stitch length at "0" and bring the needle to its tdc.
- Insert a new needle. Loosen screws 3, 4, 5 and 6.
- Bring the needle to a position directly over the bottom feed dog by turning the handwheel.
- Move the needle bar frame 7 in accordance with the requirement.
- Tighten screws 3, 4 and 5.
- Position stop 8 so that it is touching the needle bar frame 7 and tighten screw 6.




The needle bar frame 7 in guide 9 and the vibrating presser drive shaft must move freely.

## 13.04.05 Pre-adjusting the needle height

### Requirement

With the needle bar at its bdc the distance between the needle bar and the needle plate must be 15 mm.






• Move the needle bar 1 (screw 2) in accordance with the requirement without twisting it.

### 13.04.06 Driving motion of the top and bottom feed dogs

#### Requirement

With the longest stitch length set and the needle bar at its bdc the top and bottom feed dogs should not move when the reverse feed lever is activated.






- Set the longest stitch length.
- Loosen screw 1 far enough so that the feed driving eccentric 2 can be turned on the shaft with some difficulty.
- Bring the needle to its bdc.
- While keeping this position, move the feed driving eccentric 2 to the top and then move it slightly so that the **requirement** is fulfilled when the reverse feed lever is activated.
- Tighten screws 1.

## 13.04.07 Lifting motion of the bottom feed dog

(only on machines with lifting phase - P-version)

#### Requirement

- 1. With the needle bar positioned at b.d.c., the bottom feed doc should be in the t.d.c. position.
- 2. With the maximum stitch length set, when the balance wheel is turned the bottom feed dog should reach the needle plate surface at the same time as the needle point.






• Adjust eccentric 1 (screws 2) in accordance with the requirements.

### 13.04.08 Needle rise, hook-to-needle clearance and needle height

#### Requirement

With the stitch length set at "3" (1.8 mm after the bdc of the needle bar) the following must be correct:

- 1. The hook point must be opposite the middle of the needle and the distance to the needle must be 0.05 0.1 mm.
- 2. The top edge of the needle eye must be **0.8 mm** from the hook point.





- Set the stitch length at "3" and loosen screws 1 and 2 (screw 2 is on the back of the machine).
- Set the needle bar at b.d.c. and place the 1.8 mm thick feeler gauge with its cutout close under the lower needle bar bearing.
- Remove the measuring plate and turn the handwheel in its direction of rotation until the screw clamp is touching the needle bar bearing.
- Move the hook on the hook shaft in accordance with requirement 1.
- Rotate the hook in accordance with requirement 2 (adjust needle height if necessary).
- Bring the hook shaft bearing 3 to rest on the hook and tighten screw 2.
- Taking care to ensure that the bevel gear 4 is resting on the bearing 5, tighten screws 1.




On machines with a thread trimmer the adjustment of the axial play on the hook shaft and the adjustment of the hook shaft bearing 3 are not necessary.

### 13.04.09 Vibrating presser lift

### Requirement

With the vibrating presser lift at maximum and the stitch length set at "0", presser foot 1 and vibrating presser foot 2 must lift 7.0 mm from the needle plate when the handwheel is rotated.






- Set the vibrating presser lift at maximum and the stitch length at "0".
- Allow the presser foot 1 to rest on the needle plate.
- Turn the handwheel in its direction of rotation until the vibrating presser foot 2 has reached its highest point.
- Turn crank 3 (screws 4) in accordance with the requirement.
- Carry out a check.

### 13.04.10 Vibrating presser feeding motion

### Requirement

With the presser foot 3 resting on the needle plate the vibrating presser 6 and the needle point must both reach the needle plate at the same time with the vibrating presser stroke at maximum.





- Loosen nut 1.
- Slide bolt 2 upwards in the elongated hole and tighten nut 1.
- Allow the presser foot 3 to rest on the needle plate.
- Loosen screws 4 enough so that the feed lifting eccentric 5 can be rotated with difficulty.
- Rotate the lifting eccentric 5 in accordance with the **requirement**.
- Tighten screws 4.
- Carry out a check.


### 13.04.11 Needle thread tension release

### Requirement

With the presser foot lifted, the two tension disks must be at least 0.5 mm apart.



The distance of **0.5 mm** is the minimum clearance. The clearance can range up to more than **1 mm** with thick threads.





- Raise the presser foot using the hand lever.
- Align the compression plate 1 behind the tension bearing board 2 in accordance with the requirement.



When the tension is correct the release pin must not be under pressure.


## 13.04.12 Thread check spring

### Requirement

The movement of the thread check spring must be finished when the needle point enters the material (= approx. 7 mm spring movement).



The length of the spring movement can vary a little upwards or downwards due to changes in the sewing parameters.






- Adjust stop 1 (screw 2) according to Requirement.
- To adjust the pressure of the spring, turn screw 3 (screw 4).

### 13.04.13 Bobbin winder

### Requirement

- 1. With the bobbin winder engaged the winder spindle must be driven reliably. With the bobbin winder disengaged, however, the friction wheel 5 must not touch the drive wheel 1.
- 2. The bobbin winder must stop automatically when the thread wound on the bobbin has reached a point approx. **1 mm** below the bobbin rim.






- Adjust the drive wheel 1 (screws 2) in accordance with requirement 1.
- Place a bobbin on the winder spindle, thread the bobbin and switch on the bobbin winder.
- Shift the regulating pin 3 (screws 4) in accordance with requirement 2.

## 13.04.14 Regulating the pressure on the presser foot

### Requirement

The material must be fed perfectly even at top sewing speed. There must not be any pressure marks on the material.





• Turn screw 1 in accordance with the requirement.

### 13.05 Adjusting the thread trimmer -900/52




Please note that on all machines with thread trimmer -900/52 the stitch length must be limited to 5.5 mm!

## 13.05.01 Preadjusting the control cam

### Requirement

With the take-up lever at its bdc, projection 4 on the control cam 2 must be directly underneath the cam follower 5.






- Loosen screws 1 through the hole in the machine housing.
- Set the take-up lever at b.d.c.
- Turn control cam 2 according to Requirement.
- Move control cam 2 down against bearing 3 and tighten the accessible screw 1.
- Make the second screw 1 accessible and tighten it also.

## 13.05.02 Tripping lever height

### Requirement

With the needle bar at its bdc there must be a distance of 1.0 mm between the tripping lever 3 and the control cam 4.






- Bring the needle bar to its bdc by turning the handwheel.
- Move the carrier 1 (screws 2) of the tripping lever 3 in the elongated hole in accordance with the requirement.

## 13.05.03 Control pin

### Requirement

With the needle bar at b.d.c. control pin 5 must drop easily into the track of control cam 7 when engaging solenoid 6 is operated.






- Set the needle bar at b.d.c.
- Operate the solenoid core by hand.
- Turn screw 2 (nut 3) inwards until it is resting lightly against control lever 4.
- Turn screw 2 back again by about half a turn until the movement of control pin 5 corresponds with the Requirement.

### 13.05.04 Engaging solenoid

### Requirement

With the needle bar at b.d.c. and solenoid core 1 fully operated there must be a clearance of approx. 0.5 mm between locking pawl 7 and fixing collar 6.





- Set the needle bar at b.d.c.
- Push solenoid core 1 fully in.
- Position solenoid housing 2 (screw 3) according to Requirement




If solenoid housing 2 strikes against lever 4, position lever 4 (screw 5) a little farther to the left.

## 13.05.05 Control pin height

### Requirement

With the thread trimmer in its resting position and locking pawl 4 engaged there must be a clearance of 0.3 mm between the highest point of control cam 5 and control pin 6.






- Set the needle bar at t..d.c.
- Operate the solenoid core.
- Position fixing collar 2 (screws 3) according to Requirement.

## 13.05.06 Front position of thread catcher

### Requirement

With thread catcher 3 at its front position the back edge of the thread catcher cutout must be 1 mm beyond the front edge of bobbin case position stop 6.






- Set the needle bar at b.d.c.
- Operate solenoid core 1 so that control pin 2 drops into the cam track.
- Turn the balance wheel in sewing direction to set thread catcher 3 at its front position.
- Turn thread catcher 4 (screws 5) to set thread catcher 3 according to Requirement.

### 13.05.07 Lateral position of thread catcher

### Requirement

With the needle bar at b.d.c. the point of thread catcher 4 must be at the centre of the needle.





- Remove knife 1 (screws 2).
- Set the needle bar at b.d.c.
- Operate solenoid core 3 by hand and turn the balance wheel until the needle bar is at t.d.c. In doing so, make sure that thread catcher 4 does not strike bobbin case position stop 5 during its motion.
- Set lateral position of thread catcher 4 (screws 6) according to Requirement.




For further adjustments do not yet refit knife 1.

### 13.05.08 Control cam (final adjustment)

### Requirement

When the end of hook gib 2 is 2 mm behind the centre of bobbin-case position finger 3, as viewed in feeding direction, there must be a clearance of approx. 4 mm between catcher point 4 and hook gib 2.






- Set the needle bar at b.d.c.
- Operate solenoid core 1 by hand.
- Turn the balance wheel farther (sewing direction) until the end of hook gib 2, viewed in sewing direction, is 2 mm behind the centre of bobbin case position finger 3.
- Check according to requirement and re-adjust control cam if necessary, see Chapter
   13.05.01 Control cam (preliminary adjustment).

### 13.05.09 Knife

### Requirement

When the back edge of the thread catcher cutout is 1 mm in front of the knife edge, the left knife edge must be flush with the edge of the thread catcher.






- Screw on knife 1 (screws 2) finger-tight.
- Set the needle bar at b.d.c. and operate solenoid core 3.
- Turn the balance wheel (sewing direction) until the short point of thread catcher 4 is aligned with the knife edge.
- Set the lateral position of knife 1 according to Requirement (see arrow).
- Tighten screws 2.
- Turn the balance wheel to check whether the back of the thread catcher is not twisted in relation to the knife edge.
- If necessary re-adjust thread catcher 4, see Chapter 13.05.07 Lateral position of the thread catcher.

### 13.05.10 Needle thread tension release

### Requirement

When the tip of release lever 5 is at the highest point of release cam 4 the tension discs must be at least 0.5 mm apart.






- Lower the lifting presser onto the needle plate.
- Set the needle bar at b.d.c. and operate solenoid core 1.
- Turn the balance wheel (sewing direction) until the thread catcher is in its front position.
- Adjust linkage rod 2 (screws 3) according to Requirement.
- Turn the balance wheel to end the trimming action and set the take-up lever at t.d.c.
- Check that the thread tension is fully active.
- Finally, lightly grease the surfaces of release cam 4 and the tip of release lever 5.

### 13.05.11 Cutting test

### Requirement

The knife must stand parallel to the thread catcher and both threads must be reliably cut.





- Set the needle bar at b.d.c. and operate solenoid core 1.
- Turn balance wheel (sewing direction) until thread catcher 2 is in its front position.
- Take a double piece of thread, pull it into the cutout of thread catcher 2 and turn the balance wheel farther to make a cutting test.
- Check that both threads are reliably cut.
- If necessary, re-adjust thread catcher 2, see Chapter 13.05.07 Lateral position of the thread catcher.

### 13.06 Parameter settings

(only on machines with Quick-EcoDrive and control unit P40ED)

• The selection of the user level and the alteration of parameters is described in the separate instruction manual for the drive unit.

### 13.06.01 Parameter list

Group	Parameter	Description	User lever	Setting range	Set value
1	105	Speed for start backtack	В, С	300 - 2000	800
	110	Speed for end backtack	В, С	300 - 2000	1000
6	607	Speed max.	В, С	300 - 2000	<b>A</b>
	609	Cutting speed 1	В, С	60 - 300	180
7	700	Needle position 0 (needle reference position)	В, С	0 - 255	*
	702	Needle position 1 (needle lowered)	В, С	0 - 255	85
	703	Needle position 2 (take-up lever raised)	В, С	0 - 255	230
	705	Needle position 5 (end cutting signal 1)	В, С	0 - 255	100
	706	Needle position 5 (start cutting signal 2)	В, С	0 - 255	85
	707	Needle position 9 (start thread tension release/start thread catcher)	В, С	0 - 255	195
	722	Acceleration ramp	В, С	0 - 255	50
	723	Brake ramp	В, С	0 - 255	40
	734	Tact output A2 (thread trimming)	В, С	001 - 009	0
	760	Multiplier for the fixed value (200) stitch count	A,B, C	0 - 250	5
	799	Selected machine class	С	1 - 4	2
8	800	Rotating direction of the motor	С	0 - 1	1
	884	Proportional sensitivity of the speed control unit	В,С	03 - 24	10
	897	Variant mini-motor, 1 = long, 2 = short	С	0 - 1	0
9	900	Additional P- sensitivity of the speed control unit	В,С	1 - 24	9

<sup>▲</sup> See Chapter 3 Specifications

<sup>\*</sup> Adjustment see Chapter **8.04** Basic position of the machine drive unit (in the machine instruction manual).



Further parameters and the description for an internet update of the machine software and reset /cold start of the machine can be found in the instruction manual for the control panel.

# Circuit diagrams

## 14 Circuit diagrams

X40

X50

Y2

Y4 Y5

Υ8

S1-3 Control panel

-900/.. thread trimmer -910/.. automatic foot lift

-911/.. backtacking device


Thread tension release


Reference list for the Circuit diagrams

A1	Control unit Quick P40 ED
A2	Control panel BDF S2
A14	Sewing head recognition system (OTE)
H1	Sewing lamp (optional)
H10	LED stitch counter
M1	Sewing motor
Q1	Main switch
S1	Manual backtacking key
S1.1	Pedal speed control unit
S2	Needle position change key
S3	Single stitch key
S6	Start inhibitor (E6 stop)
X0	PC-interface (RS 232)
X1	Motor
X2	Incremental transducer
X2.1	Incremental transmitter adapter
X2.2	Synchronizer adapter
X2.3	Y5-911/ backtacking device
X3	Speed control unit
X3.1	Y2-900/ thread trimmer (FS)
X4	A2 control panel plug BDF S2
X4.1	Y4 -910/ automatic foot lift
X5	Out-/input
X6	Bobbin thread monitor (optional)
X6.1	Y8Thread tension release
X7	Photoelectric barrier (optional)
X22	Y2 -900/ thread trimmer (FS)
X24	Y4 -910/ automatic foot lift
X25	Y5 -911/ backtacking device
X28	Y8 Thread tension release

32 PFAFF

A14 Sewing head recognition system (OTE)





RS232-Schnittstelle 9 poliger D-SUB Stecker  $\wedge \, 0$ D×A T×D  $\times$ Unterfadenwächter Lichtschranke UFW OUT LS LS OV 0V +5V BN 6 polig Western Stecker (Option)  $\otimes$ BK BU B7 Quick P40 ED (Option) Steuergerät A1 37 36 Sonderfunktionen 35 34 33 X 32 ۸0 61 YE WH 0110100101 0110001110 0011100101 8 Et10 22IN A14 0TE S3 A13, SSCLK N D 23 |  $\widetilde{\Xi}$ ۷5+ ک X50



### PFAFF Industrie Maschinen AG

Postfach 3020 D-67653 Kaiserslautern

Königstr. 154

D-67655 Kaiserslautern

Telefon: (0631) 200-0 Telefax: (0631) 17202

E-Mail: info@pfaff-industrial.com