

**SINGER**  
**144W201,W301**

# USE ONLY SINGER OILS and LUBRICANTS

*They insure freedom from lubricating trouble and  
give longer life to sewing equipment*

## “Singer Oil for High Speed Sewing Machines”

(Cloth and Leather)

For all manufacturing sewing machines except where a stainless oil is desired.

## “Singer Stainless Oil for High Speed Sewing Machines”

For all manufacturing sewing machines where a stainless oil is desired.

## “Singer Motor Oil”

For oil-lubricated motors, power tables, transmitters and machinery in general.

## “Singer Stainless Thread Lubricant”

For lubricating the needle thread of sewing machines for stitching fabrics or leather where a stainless thread lubricant is required.

*NOTE: All of the above oils are available in 1 quart, 2 quart, 1 gallon and 5 gallon cans or in 55 gallon drums, and can also be supplied in customer's containers.*

## “Singer Gear Lubricant”

This specially prepared grease is recommended for gear lubrication on manufacturing sewing machines.


## “Singer Ball Bearing Lubricant”

This pure grease is specially designed for the lubrication of ball bearings and ball thrust bearings of motors and electric transmitters, ball bearing hangers of power tables, etc.

*NOTE: The above greases are furnished in ¼ lb. tubes and 1 lb. and 4 lb. tins.*

Copyright, U. S. A., 1914, 1924, 1934, 1935 and 1936,  
by The Singer Manufacturing Company  
All Rights Reserved for all Countries

## INSTRUCTIONS For Using and Adjusting SINGER SEWING MACHINES



144w201 and 144w301

THE SINGER MANUFACTURING COMPANY

## DESCRIPTION

To all whom it may concern:

The placing or renewal of the name "Singer" (Reg. U. S. Pat. Off.) or any of the trade marks of The Singer Manufacturing Company on any machine that has been repaired, rebuilt, reconditioned, or altered in any way whatsoever outside a Singer factory or an authorized Singer agency is forbidden.

---

### THE IMPORTANCE OF USING GENUINE SINGER PARTS AND NEEDLES IN SINGER MACHINES

The successful operation of Singer machines can only be assured if genuine Singer parts and needles are used. Supplies are available at all Singer Shops for the Manufacturing Trade and mail orders will receive prompt attention.

Genuine Singer Needles should be used  
in Singer Machines.  
These Needles and their Containers  
are marked with the  
Company's Trade Mark "SIMANCO." 1

Needles in Containers marked  
"For Singer Machines"  
are not Singer made needles. 2

MACHINE 144W201 is a single-needle lock stitch machine with compound feed and high-lift alternating pressers. It is used for stitching pockets in automobile door panels, and for tarpaulins, awnings and similar work. It has a high arm with a working space of 20 inches at the right of the needle.

MACHINE 144W301 is the same as the 144W201 machine but has a longer arm, with a working space of 30 inches at the right of the needle.

### Speed

The maximum speed recommended for these machines is 1500 revolutions per minute, when permitted by the nature of the material being sewn. The machines should be run slower than the maximum speed until the parts which are in movable contact have become glazed by their action on each other. When the machines are in operation, the balance wheel should turn over toward the operator.

### Needles

Needles for the above machines are of Class and Variety 7x3, for cloth, made in sizes 21,22,23,24,25,26 and 27, or 7x19 for panel work, made in sizes 22,23,24,25 and 27.

The size of the needle to be used should be determined by the size of the thread, which must pass freely through the eye of the needle. If rough or uneven thread is used, or if it passes with difficulty through the eye of the needle, the successful use of the machine will be interfered with.

Orders for needles must specify the quantity required, the size number, also the class and variety numbers separated by the letter x.

The following is an example of an intelligible order:

"100 No. 24, 7x3 Needles."

The best results will be obtained when using the needles furnished by the Singer Sewing Machine Company.

### Oiling the Machine

When the machines are received from the factory, they should be thoroughly cleaned and oiled. When in continuous use, they should be oiled at least twice a day.




Fig. 2  
Front View of Machine  
Showing Oiling Points

Oil should be applied at each of the places designated by arrows in Figs. 2, 3, 4 and 5.




Fig. 3  
Rear View of Machine  
Showing Oiling Points and Adjustments

Loosen the thumb screw in the upper end of the face plate, turn the face plate upward and oil the wick and bearings which are thus uncovered, then turn down the face plate and tighten the thumb screw.




Fig. 4. End View of Machine Showing Oiling Points  
Also Adjustments on the Machine

Apply a few drops of oil four times daily to the two felt pads in the side wall of the bobbin case as illustrated in Fig. 9.




Fig. 5. Base of Machine Showing Oiling Points and Adjustments

## Thread

Use left twist thread for the needle. Either left or right twist thread may be used for the bobbin.




Fig. 6. How to Determine the Twist

Hold the thread as shown above. Turn the thread over toward you between the thumb and forefinger of the right hand; if left twist, the strands will wind tighter; if right twist, the strands will unwind.

## To Set the Needle

Turn the balance wheel over toward you until the needle bar moves up to its highest point; loosen the set screw in the needle bar and put the needle up into the bar as far as it will go, with its long groove toward the left, the eye of the needle being directly in line with the machine bed, then tighten the set screw.

## To Remove the Bobbin

Draw back the slide plate in the bed of the machine and turn the balance wheel until the bobbin case opener (M, Fig. 7) moves clear of the bobbin. With the forefinger or a screwdriver, raise the latch (L) to a vertical position and lift out the bobbin.




Fig. 7. Removing the Bobbin

## To Wind the Bobbin

(See Fig. 8)

Place the bobbin on the bobbin winder spindle and push it up against the shoulder until it is in line with the bobbin winder latch.




Fig. 8. Winding the Bobbin

Pass the thread from the unwinder, under and between the tension discs (1), through the eyelet (2), and wind the end of the thread around the bobbin (3) a few times. Push the bobbin winder pulley against the balance wheel and press the latch against the bobbin. When sufficient thread has been wound on the bobbin, the bobbin winder will stop automatically. Bobbins can be wound while the machine is stitching.

### To Replace the Bobbin and Thread the Bobbin Case

Hold the bobbin between the thumb and forefinger of the right hand, the thread drawing on the bottom from left to right as shown




Fig. 9. Direction of Thread on Bobbin

in Fig. 9, and place it on the center stud of the bobbin case, then push down the latch (L, Fig. 10). Draw the thread into the slot (1, Fig. 9) and under the tension spring (2) as shown in Figs. 9 and 10, leaving a loose end of thread about two inches long above the slide. When closing the slide plate, leave just enough space for the thread to pass through.




Fig. 10. Bobbin Case Threaded

### Threading the Needle

(See Fig. 11)

Pass the thread from the unwinder through one of the holes (1) in the thread oiler, and under the wire guide (2) (which may be




Fig. 11

raised by prying the end (X) out of its position hole with a screwdriver and turning it to the right), then under the oil pad (3) and out through one of the notches (4) in the thread oiler; downward to the thread guide, up through the eyelet (5), down through the eyelet (6), over between the tension discs (7), down around the thread controller (8) and into the tension thread guide (9), into the thread take-up spring (10), up through the guide (11), from right to left through the hole (12) in the take-up lever, down through the guide (13), into the thread guide (14), into the self-threading needle bar thread guide (15) and from left to right through the eye (16) of the needle.

### To Raise or Lower the Presser Feet

The presser feet are raised by pressure on the foot treadle and may be locked in the raised position by moving the lever (A, Fig.2) all the way to the left. A slight pressure on the treadle will automatically release the locking device.

### To Prepare for Sewing

With the left hand hold the end of the needle thread, leaving it slack from the hand to the needle. Turn the balance wheel over




Fig. 12 Pulling Up the Bobbin Thread

toward you until the needle moves down and up again to its highest point, thus catching the bobbin thread; draw up the needle thread and the bobbin thread will come up with it through the hole in the feed dog. Lay the threads back under the presser feet and close the slide.

### To Commence Sewing

Place the material beneath the presser feet, lower the presser feet and commence to sew, turning the balance wheel over toward you.

### To Remove the Work

Have the thread take-up lever at the highest point, raise the presser feet, draw the work back and cut the threads close to the goods. Lay the ends of the threads back under the presser feet.

### Tensions

The needle and bobbin threads should be locked in the center of the thickness of the material, thus:




Fig. 13. Perfect Stitch

If the tension on the needle thread is too tight, or if that on the bobbin thread is too loose, the needle thread will lie straight along the upper surface of the material, thus:




Fig. 14. Tight Needle Thread Tension

If the tension on the bobbin thread is too tight, or if that on the needle thread is too loose, the bobbin thread will lie straight along the under side of the material, thus:



Fig. 15. Loose Needle Thread Tension

### To Regulate the Tensions

The tension on the needle thread is regulated by the thumb nut (Q, Fig.17) at the front of the tension discs on the front of the machine. To increase the tension, turn this thumb nut over to the right. To decrease the tension, turn this thumb nut over to the left.

The tension on the bobbin thread is regulated by means of the screw nearest the center of the tension spring on the outside of the bobbin case. To increase the tension, turn this screw over to the right. To decrease the tension, turn this screw over to the left.

### To Regulate the Length of Stitch

The length of stitch is regulated by the feed regulating spindle (A, Fig. 16) at the right of the balance wheel.




Fig. 16. Stitch Regulator

To lengthen the stitch, turn the feed regulating spindle (A) over toward you. To shorten the stitch, turn this spindle over from you.

### To Regulate the Pressure on Material

To increase the pressure, turn the thumb screw (D, Fig. 3) at the back of the machine, downwardly. To decrease the pressure, turn this thumb screw upwardly.

The pressure on the material should only be sufficient to enable the feed to move the work along evenly.

## INSTRUCTIONS FOR ADJUSTERS AND MACHINISTS

### Thread Controller

The thread controller spring should be set so that it reaches its lowest point as the eye of the needle nearly reaches the goods in its descent.




Fig. 17. Adjustment of Thread Controller

For more controller action on the thread, loosen the stop screw (O, Fig. 17) at the right of the tension and set the stop lower, and for less action set the stop higher.

To strengthen the action of the controller spring on the thread, loosen the tension stud screw (P, Fig. 17) at the right of the stop screw and turn the tension stud (N, Fig. 17) slightly to the left with a screwdriver, or to lighten its action turn to the right and retighten the tension stud screw.



### To Set the Needle Bar

See that the needle is up in the bar as far as it will go. There are two lines across the needle bar about two inches above the lower end. When the needle bar is at its lowest position, the upper mark should be just visible at the end of the needle bar frame.

In case the needle bar is not correctly set, loosen the needle bar connecting stud pinch screws(F, Fig.4) and place the needle bar in correct position as directed above, then retighten the screws (F).

### To Set a Needle Bar Which Has No Mark

Turn the feed regulating spindle (A, Fig.16) so that there is no feed movement of the needle bar, then set the needle bar so that when it rises 1/8 inch from its lowest position, the point of the sewing hook will be about 1/16 inch above the eye.

### Relative Positions of Vibrating Presser Bar and Lifting Presser Bar

The distance between the vibrating presser bar and lifting presser bar, after turning the feed regulating spindle head so that there is no feed movement of the needle bar, should be 5/8 inch as shown in Fig. 4.

If the distance between the vibrating presser bar and the lifting presser bar is more or less, insert a screwdriver in the hole at (C, Fig.3) at the rear of the machine and loosen the clamp screw which holds the needle bar rock frame rock shaft. While this screw is loose, the needle bar frame can be moved forward or backward to the required distance. A piece of metal of the correct width may be used to determine the correct distance. When making this adjustment be sure to see that the feed regulating spindle head is set so that there is no feeding movement of the needle bar. When the adjustment has been made, securely tighten the clamp screw at C.

### To Adjust the Relative Height of Lift of the Vibrating and Lifting Pressers

The amount of lift of the vibrating and lifting presser feet should be regulated according to the thickness of the material being sewn. The feet should lift just high enough to clear the material. As a rule, the vibrating and lifting pressers should lift an equal height, but some grades of work may require that they lift an unequal height. To change the relative lift of the presser feet, loosen the screw (E, Fig.3) at the back of the machine and move the vibrating presser bar upward or downward as required, then securely tighten the screw (E).

### To Time the Sewing Hook

Set the feed regulating spindle so that there is no feeding motion.

Remove the throat plate and turn the balance wheel over toward you until the lower mark across the needle bar is just visible at the end of the needle bar frame on the upward stroke of the needle bar. If the needle bar and sewing hook are correctly timed, the point of the hook will be at the center of the needle and about 1/16 inch above the eye.

In case the sewing hook is not correctly timed, turn the balance wheel over toward you until the needle bar has descended to its lowest point and has risen until the lower timing mark across the needle bar is just visible at the end of the needle bar frame.

Loosen the two screws (T, Fig.18) in the hub of the hook driving gear (U, Fig.18) and tap this gear to the right or left on the hook driving shaft until the point of the hook is at the center of the needle. Tapping to the right gives an earlier hook timing, and to the left a later hook timing. Securely tighten the two set screws (T) in the gear.

### To Set the Sewing Hook to or from the Needle

To prevent the point of the hook from dividing the strands of the thread, it should run as close to the needle (within the scarf) as possible.




Fig. 18. Adjustment of Hook Saddle

Turn the balance wheel over toward you until the point of the sewing hook is at the center of the needle. Loosen the two screws (V, Fig. 18) underneath the bed of the machine and move the hook saddle to the right or left, as may be required, until the point of the hook is as close to the needle as possible without striking it, then securely tighten the two screws (V).

The needle guard (Y, Fig. 20), which is attached to the side of the sewing hook, should be sprung until it prevents the needle from striking the hook in case the needle is deflected towards the hook.




Fig. 19. Removing Bobbin Case

### To Remove the Bobbin Case from the Sewing Hook

Remove the bobbin case opener (M, Fig. 7); remove the four hook gib screws (W, Fig. 19) from the sewing hook, lift off the hook gib (Z, Fig. 20) and remove the bobbin case (X, Fig. 19).

### To Remove the Sewing Hook from the Machine

Remove the throat plate, feed dog and the bobbin case opener. Loosen the two screws in the hook shaft gear (R, Fig. 18) and lift out the sewing hook.




Fig. 20. Sewing Hook Removed from Machine  
Showing Hook Washer

### To Raise or Lower the Feed Dog

Usually when the feed dog is at its highest position, it should show a full tooth above the throat plate.

Remove the throat plate; clean the lint and dust from between the feed points and replace the throat plate; tip the machine back and turn the balance wheel towards you until the feed dog is at its highest position; loosen screw (S, Fig. 18) in the feed lifting cam fork on the feed bar and raise or lower the feed dog, as may be required, and retighten the screw (S).

When raising or lowering the feed dog, be careful that its underside does not drop low enough to strike the sewing hook.

The feed dog should be set so that the needle is centered in the needle hole. In case the needle does not enter the hole in the feed dog correctly, loosen the pinch screw (G, Fig. 5) and adjust the feed dog as required, then securely tighten the pinch screw (G).

### Adjustment of Feed Regulating Spindle

The figures on the feed regulating spindle (DD, Fig. 21), showing through the notch in the balance wheel, indicate the number of




Fig. 21. "X-Ray" View of Feed Driving Eccentric Regulating Bracket and Shaft, Showing the Feed Regulating Spindle and Adjusting Screw (CC) Which Comes in Contact with the Cone of the Spindle to Gauge the Length of Stitch

stitches to the inch which should be made. If more or less stitches are made, adjust as follows: Remove screw (BB, Fig. 21), set the indicator at 2 1/2 and the feed dog at its highest point, a full tooth showing above the throat plate, then adjust screw (CC, Fig. 21) until 2 1/2 stitches to the inch is the result and replace check screw (BB) firmly.

By making this adjustment with the stitch indicator set at 2 1/2 stitches, the full range of the stitch regulator is automatically taken care of so that the number appearing in the notch in the balance wheel will indicate the correct number of stitches to the inch that the machine should make.

TO SET THE FEED REGULATOR SO THAT A STITCH LONGER THAN THE ONE DESIRED CANNOT BE MADE. Turn the feed regulating spindle (DD, Fig. 21) as far as possible in the direction indicated by the arrow in Fig. 21; remove check screw (BB) and adjust screw (CC) until the machine makes the desired number of stitches to the inch, then turn screw (BB) down tightly on screw (CC) as a check. The stitches may then be changed by turning the feed regulating spindle (DD) for shorter stitches, but operators cannot make a longer stitch than that limited by the above adjustment.

### To Remove the Needle Bar Rock Frame Rock Shaft

Remove the face plate and needle bar rock frame, then loosen the clamp screw at (C, Fig. 3) and draw out the rock shaft.

### To Remove the Arm Shaft Connection Belt from within the Arm

Slide the connection belt off lower pulley (K, Fig. 5); remove the feed regulating spindle and balance wheel; loosen the three screws in the arm shaft bushing near the balance wheel and remove the bushing; lift the belt up through the arm cap hole as far as possible and draw it out through the space normally occupied by the bushing.

Owing to the fact that the sewing hook makes two revolutions to one revolution of the arm shaft, and that the feed lifting eccentric is on the hook shaft, it is possible to have the sewing hook correctly timed without having the feed correctly timed. To overcome this, the plate (H, Fig. 5) is attached to the underside of the bed of the machine. This plate is marked with an arrow at its lower end and directly alongside of the plate is the collar (J, Fig. 5) mounted on the hook shaft, which is also marked with an arrow. After replacing the belt over the upper pulley, replace the arm shaft bushing and securely fasten it in position by its three screws; replace the feed regulating spindle and the balance wheel. With the belt on the upper pulley, turn the balance wheel toward you until the thread take-up lever is at its highest point. Then turn the hook shaft with the fingers until the two arrows, one on the plate (H) and the other on the collar (J), are directly in line. Now, without disturbing either the arm shaft or the hook shaft, slip the belt over the lower pulley. The feed will then be correctly timed with the needle bar.




Fig. 22. Putting Belt on Lower Pulley with Belt Replacer 265058

To facilitate the replacing of the belt on the lower pulley, use belt replacer 265058 (A, Fig. 22). Rest the replacer in the loop of the belt and slide it over the hub of the pulley, as shown in Fig. 22, having the notches in the replacer engage the two set screws in the hub of the pulley. Catch the belt clips in the

groove at the lower part of the pulley and turn the balance wheel from you until the belt is fully over the pulley, assisting the belt clips from under the pulley rim with a screwdriver when necessary. Then remove the replacer.

NOTE: As belt replacer 265058 will serve for several machines it is not regularly furnished with the machine, and must be ordered separately.

### To Re-engage the Safety Clutch

The hook driving shaft and the shaft of the sewing hook are splined to prevent the hook from getting out of time. The safety clutch located in the lower belt pulley prevents damage in the event of thread jamming in the sewing hook by releasing the locking lever in the pulley from the notch (D1, Fig. 24) in the collar of the hook driving shaft.




Fig. 23. Safety Clutch Disengaged      Fig. 24. Operating Position

Re-engage the clutch by pressing down on the lock stud (B, Fig. 2) near the base of the arm, and turning the balance wheel away from you until the locking lever (B1) snaps into the notch (D1, Fig. 24) in the shaft collar as shown in Fig. 24. Release the lock stud (B), draw back the bed slide, turn the balance wheel back and forth slightly and remove the material that may be jammed in the hook, then resume sewing.

Genuine Singer Needles should be used  
in Singer Machines.  
These Needles and their Containers  
are marked with the  
Company's Trade Mark "SIMANCO." 1

Needles in Containers marked  
"For Singer Machines"  
are not Singer made needles. 2