


3018w

INSTRUCTIONS
FOR USING AND ADJUSTING

SINGER*
SEWING MACHINES

400w21, 400w22, 400w23, 400w24,
400w28, 400w29 and 400w33



SINGLE NEEDLE

LOCK STITCH

Special attention is called to the lubricating instructions
on pages 5 to 7.

*A TRADE MARK OF
THE SINGER MANUFACTURING COMPANY

TO ALL WHOM IT MAY CONCERN:

The improper placing or renewal of the Trade Mark "SINGER" or any other of the Trade Marks of The Singer Manufacturing Company (all of which are duly Registered Trade Marks) on any machine that has been repaired, rebuilt, reconditioned, or altered in any way whatsoever outside a SINGER factory or an authorized SINGER agency is forbidden.

THE IMPORTANCE OF USING **SINGER*** PARTS AND NEEDLES IN **SINGER** MACHINES

The successful operation of SINGER machines can only be assured if SINGER parts and needles are used. Supplies are available at all SINGER Shops for the Manufacturing Trade, and mail orders will receive prompt attention.

SINGER Needles should be used
in SINGER Machines.
These Needles and their Containers
are marked with the
Company's Trade Mark "SIMANCO.*" 1

Needles in Containers marked
"FOR SINGER MACHINES"
are NOT **SINGER** made needles. 2

Copyright, U. S. A., 1914, 1915, 1922, 1926, 1935, 1940,
1941, 1944, 1945, 1946, 1947, 1948 and 1951
by The Singer Manufacturing Company
All Rights Reserved for All Countries

DESCRIPTION

Machine 400w21 is a high speed, single needle, lock stitch machine equipped with a double rotary thread take-up. It has a belt-driven, automatically lubricated rotary sewing hook on a horizontal axis. The drop feed is adjustable for stitches from 5-1/2 to 30 per inch. The needle bar stroke is 1-9/64 inches and the maximum presser bar lift is 9/32 inch. The machine is used for stitching light and medium weight fabrics.

Machine 400w22 is the same as Machine 400w21 except that it has a 5/16" presser bar lift and is adapted for stitching medium and heavy weight fabrics.

Machine 400w23 is the same as Machine 400w22 except that it has a ball bearing roller presser for stitching light weight leather.

Machine 400w24 has an auxiliary puller feed and is specially fitted for stitching slide fastener cords onto tape, otherwise same as Machine 400w21.

Machine 400w28 produces continuous rows of stitching on the brims of sailors' white hats. It has mechanism for placing 75 to 80 rows of stitching within a space of approximately 2-5/8 inches in width around the brim. It has an automatic machine stop device which stops the machine at the conclusion of a predetermined number of spiral rows of stitching around the hat brim. Clearance under presser foot 3/16". Same stitching mechanism as Machine 400w21. For special adjustments, see Pages 36, 37 and 38.

Machine 400w29 has a bed 6-3/16 inches wide and is mounted on an iron base which raises the top surface of the bed 6 inches above the table, affording the advantages of a cylinder bed. It is especially adapted for stitching tubular articles made of light and medium weight fabrics. The presser bar lift is 3/16 inch. Same stitching mechanism as Machine 400w21.

Machine 400w33 is regularly equipped with a 3/16" hemmer and has a mechanical hem deflector which is operated from the bed shaft to produce a scallop at every sixth stitch, forming a neat and attractive shell edge stitching effect on ladies' lingerie, children's underwear, dresses, etc. Same stitching mechanism as Machine 400w21. For special adjustments, see Pages 39 and 40.

SPEED

The maximum speeds recommended for these machines, depending on materials used and operations performed, are as follows:

Machine	Maximum Speed
400w21 400w22 400w23 400w29 400w33	5000 R. P. M.
400w24	4000 R. P. M.
400w28	3000 R. P. M.

It is advisable to run a new machine slower than the maximum speed for the first few minutes to allow time for the oil to reach the moving parts. The machine pulley turns over from the operator.

SETTING UP

The drip pan should be attached with its right end even with the right end of the cut-out and low enough in the cut-out to avoid interference with the knee lifter rod **A**, Fig. 2. Fig. 2 shows the correct location of the knee lifter. The knee lifter bracket should be assembled so that the lifter rod **A** does not strike the drip pan. The screw slots in the bracket provide the necessary adjustment. The stop stud **B**, Fig. 2 should be set to stop the action of the knee lifter as soon as the presser foot is raised enough to trip the hand lifter.




Fig. 2. Position of Knee Lifter Under Table

CAUTION: Do not start a machine, not even to test the speed, until it has been thoroughly oiled as instructed on Pages 5 and 6.

OILING THE MACHINE

Use "**TYPE A or TYPE C**" OIL, sold only by Singer Sewing Machine Company for 241-, 400w and 410w Machines. For description of oils, see inside of front cover.

A reservoir in the bed of the machine supplies oil to the sewing hook race and to the bearings and eccentrics on the hook driving shaft (except the rear ball bearing). The other lubrication points are reached by seven oil holes, marked with red. See "X-Ray" view of machine on Pages 20 and 21.

BEFORE STARTING THE MACHINE, fill the oil reservoir (through the oil gauge hole) to the top mark on the oil gauge **E**, Fig. 3.




Fig. 3. Showing the Eight Oiling Points on the Machine

While it may not be necessary to add oil to the reservoir every day, the oil level must be checked **DAILY** and filled to the high mark. Never allow the oil level to drop below the lower mark on the oil gauge.

AT THE BEGINNING OF EACH WORKING DAY, turn the machine pulley until the needle is **ALL THE WAY UP**, and place **A FEW DROPS** of oil in each of the seven oil holes indicated by the arrows in Fig. 3.

TO OIL MACHINE 400w28

This machine should be oiled as instructed on **Page 5**, and in addition oil should be applied to the places, as instructed below:




Fig. 4. Showing Oiling Points on the Machine also Adjustments

To oil the moving parts in the machine base, remove the hat brim guide **B, Fig. 4**, by turning the knurled knob **C, Fig. 4** to the left as far as it will go, then draw the brim guide to the left and remove it from the machine. Release the latch **G, Fig. 4** and tilt the machine back on its hinges so that the moving parts in the machine base can be oiled as follows:

Pour oil into the reservoirs **J and K, Fig. 5**, until it overflows into the machine base. Inspect the oil level in these reservoirs twice daily. (The thread on the lead screw **A, Fig. 4** must be kept free of oil to prevent lint from collecting on it).

CAUTION. Before machine is returned to normal position, it is very important to see that the driving pin **H, Fig. 5** is at its highest point and that the driven pin **L, Fig. 5** is at its lowest point. This will prevent damage to the pins **H and L**.




Fig. 5. Showing Oil Reservoirs in Base of Machine also Adjustments

NEEDLES

Needles for these machines are as follows:

Machine	Class and Variety	Sizes
400w21 400w24 400w29 400w33	88x1	7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 18, 19 and 21
400w22	135x5	7, 8, 9, 10, 11, 12, 13, 14, 16, 18, 20 and 21
400w23	88x2	10, 11, 12, 14, 16, 18 and 19
400w28	135x7	7, 8, 9, 10, 11, 12, 14, 16, 18, 20 and 21

The above needles regularly have nickel finish, but can be supplied with chromium finish if ordered.

The size of the needle to be used should be determined by the size of the thread, which must pass freely through the eye of the needle. Rough or uneven thread, or thread which passes with difficulty through the eye of the needle, will interfere with the successful use of the machine.

Orders for needles must specify the **Quantity** required, the **Size** number; also the **Class** and **Variety** numbers separated by an **x**.

The following is an example of an intelligible order:
"50 No. 16, 88x1 Needles."

The best stitching results will be obtained by using the needles sold by Singer Sewing Machine Company.

THREAD

Left twist thread should be used in the needle. Either right or left twist thread can be used in the bobbin.




Fig. 6. How to Determine the Twist

Hold the thread as shown above. Turn the thread over toward you between the thumb and forefinger of the right hand; if left twist, the strands will wind tighter; if right twist, the strands will unwind.

TO REMOVE THE BOBBIN

Turn the machine pulley over from you until the needle moves up to its highest position. Draw back the slide in the bed of the machine.




Fig. 7. Removing the Bobbin

Reach under the table and open the bobbin case latch **D**, Fig. 7 and, by means of this latch, remove the bobbin case from the sewing hook.

While the latch remains open, the bobbin will be retained in the bobbin case. Release the latch, turn the open end of the bobbin case downward and the bobbin will drop out.

TO WIND THE BOBBIN

(See Fig. 8)

Fasten the bobbin winder to the table with its driving pulley in front of the machine belt, so that the pulley will drop away from the belt when sufficient thread has been wound upon the bobbin.




Fig. 8. Winding the Bobbin

Place the bobbin on the bobbin winder spindle and push it on as far as it will go.

Pass the thread down through the thread guide **1** in the tension bracket, around the back of, and between, the tension discs **2**. Then wind the end of the thread around the bobbin a few times in the direction shown in Fig. 8, push the bobbin winder pulley over against the machine belt and start the machine.

When sufficient thread has been wound upon the bobbin, the bobbin winder will stop automatically.

If the thread does not wind evenly on the bobbin, loosen the screw **A** in the tension bracket and move the bracket to the right or left as may be required, then tighten the screw.

The amount of thread wound on the bobbin is regulated by the screw **B**. To wind more thread on the bobbin, turn the screw **B** inwardly. To wind less thread on the bobbin, turn this screw outwardly.

Bobbins can be wound while the machine is stitching.

When winding a bobbin with fine thread, a light tension should be used.

TO THREAD THE BOBBIN CASE




Fig. 9

With the left hand hold the bobbin case as shown in Fig. 9, the slot in the edge being near the top, and place the bobbin into it.

Hold the bobbin between the thumb and forefinger of the right hand, as shown in Fig. 9, the thread drawing on the top from the left toward the right.



Fig. 10

Then pull the thread into the slot in the edge of the bobbin case as shown in Fig. 10, draw the thread under the tension spring and into the delivery eye at the end of the tension spring. See Fig. 11.




Fig. 11

TO REPLACE THE BOBBIN CASE

After threading, take the bobbin case by the latch and place the bobbin case on the center stud C, Fig. 7 of the bobbin case holder;




Fig. 12. Bobbin Case Threaded and Replaced

release the latch and press the bobbin case back until the latch catches the groove near the end of the stud. See Fig. 12. Allow about two inches of thread to hang free, and replace the slide in the bed of the machine.

TO SET THE NEEDLE

Turn the machine pulley over from you until the needle bar moves up to its highest point; loosen the screw at the lower end of the needle bar and put the needle up into the bar or clamp as far as it will go, with the long groove of the needle toward the left and the eye of the needle directly in line with the arm of the machine; then tighten the screw.

UPPER THREADING

(See Fig. 13)

As soon as an operator has become accustomed to threading the machine, the thread can be passed from the thread retainer at the top, down to the needle with a single continuous motion.

Turn the machine pulley over from you until the two pins **P** in the rotary take-up are directly toward the front, as shown in Fig. 13 inset.

Pass the thread from the unwinder through the top hole **1** in the pin on top of the machine, then around and through the lower hole **2** in the pin, thence through the three holes **3, 4** and **5** in the thread retainer. Hold the thread with the right hand near the thread retainer while passing the thread, with the left hand, downward into the inner slot **6** (guiding it into the hole **7**) and on down in front of the tension discs **8**, around between the tension discs into the take-up spring **9** and under the thread pull-off **10**, then over through the slot **11**, allowing the thread to fall in place over the take-up discs. Now release the thread with the right hand, and pass it down through the guides (**12, 13** and **14**), then from left to right through the eye of the needle **15**. Leave about three inches of thread with which to commence sewing.




Fig. 13. Threading the Needle

NOTE: The thread guide **14** should be turned on the needle bar bushing so that the thread leads in a straight line from the guide **13** to the needle eye. The thread retainer **5** should be turned so that the thread leads through the center of hole **7**.

TO PREPARE FOR SEWING

With the left hand hold the end of the needle thread, leaving it slack from the hand to the needle, turn the machine pulley over from you until




Fig. 14. Drawing Up the Bobbin Thread

the needle moves down and up again to its highest point, thus catching the bobbin thread; draw up the needle thread and the bobbin thread will come up with it through the hole in the throat plate. See Fig. 14. Lay both threads back under the presser foot.

TO COMMENCE SEWING

Place the material beneath the presser foot, lower the presser and commence to sew, turning the machine pulley over from you.

TO REMOVE THE WORK

Stop the machine when the needle bar has just started to descend or with the two pins **P**, Fig. 13 in the rotary take-up directly toward the front. In this position the upper thread will be free of the sewing hook and the take-up will not unthread the needle when the machine is started. Raise the presser foot, draw the work back and cut the threads close to the work.

INSTRUCTIONS FOR USE OF THREAD SEVERING DEVICE




Fig. 15

When thread breaks at operating speeds, loops of thread from small take-up disc may accumulate on Thread Severing Finger, as shown in Fig. 15.

Operator grasps loops of thread and severs them across sharpened edge of Thread Severing Finger, as shown in Fig. 16.




Fig. 16




Fig. 17

At low speed, loops of thread may remain over the tapered pin of the small take-up disc. When this occurs, the operator opens the guard, as shown in Fig. 17, removes the loops from the tapered pin and severs them as described above. Usually the machine will clear itself when it is again started.

TENSIONS

For ordinary stitching, the needle and bobbin threads should be locked in the center of the thickness of the material, thus:



Fig. 18. Perfect Stitch

If the tension on the needle thread is too tight, or if that on the bobbin thread is too loose, the needle thread will lie straight along the upper surface of the material, thus:



Fig. 19. Tight Needle Thread Tension

If the tension on the bobbin thread is too tight, or if that on the needle thread is too loose, the bobbin thread will lie straight along the under side of the material, thus:



Fig. 20. Loose Needle Thread Tension

TO REGULATE THE TENSIONS

THE TENSION ON THE NEEDLE THREAD SHOULD BE REGULATED ONLY WHEN THE PRESSER FOOT IS DOWN. Having lowered the presser foot, turn the small thumb nut at the front of the tension discs over to the right to increase the tension. To decrease the tension, turn this thumb nut over to the left.

The tension on the bobbin thread is regulated by the large screw **FF**, Fig. 9 in the tension spring on the outside of the bobbin case. To increase the tension, turn this screw over to the right. To decrease the tension, turn this screw over to the left.

When the tension on the bobbin thread has been once properly adjusted, it is seldom necessary to change it, as a correct stitch can usually be obtained by varying the tension on the needle thread.

TO REGULATE THE PRESSURE ON THE MATERIAL

The pressure of the presser foot on the material is regulated by the screw **F**, Fig. 21, in the top of the arm. Turn this screw to the right to increase the pressure or to the left to decrease the pressure. The pressure should be set only sufficiently strong to satisfactorily feed the work.




Fig. 21. Stitch Regulator and Indicator on Machine 400w21

TO REGULATE THE LENGTH OF STITCH

To change the length of stitch, press down the stud **H**, Fig. 21 in the bed of the machine and at the same time turn the machine pulley slowly until the stud enters a notch in the adjustable feed eccentric cam. Still holding the stud, turn the machine pulley a part of a revolution until the number indicating approximately the number of stitches per inch desired appears in the hole **G** over the large take-up disc, then release the stud. **DO NOT TOUCH THE STUD (H) WHILE THE MACHINE IS RUNNING.**

HINTS FOR PERFECT OPERATION

Follow instructions and oil machine regularly.

The machine pulley must always turn away from the operator.

Do not run machine with bobbin case only partly inserted.

Do not run the machine with the presser foot resting on the feed without cloth under the presser foot.

Do not run the machine when both bobbin case and needle are threaded unless there is material under the presser foot.

Do not try to help the machine by pulling the fabric lest you bend the needle. The machine feeds the work without assistance.

The slide over the bobbin case should be kept closed when the machine is in operation.

Do not press on the knee lifter lever while the machine is in operation, as this might prevent the work from feeding properly.

Occasionally remove the accumulation of lint from around the hook and from between the feed rows beneath the throat plate.

NEVER TOUCH THE STITCH REGULATOR STUD WHEN THE MACHINE IS RUNNING.

NOTE: The instructions on the following pages are for Adjusters and Mechanics only.

TIMING THE MACHINE

The parts are in their proper timing on the various shafts when the locating screws are in the shaft splines provided for them. These locating screws are the first screws appearing when the shafts are revolved in their normal direction of rotation.




Fig. 22. Showing Timing Marks on Take-up Discs and Face Plate

The arm shaft, auxiliary take-up shaft and hook driving shaft with their component parts are in time with each other when the arrow **G**, **Fig. 22** on the large take-up disc is in line with mark **GG**, **Fig. 22** on the face plate, the arrow **X**, **Fig. 22** on the small take-up disc is in line with mark **XX** on the face plate, and the arrow on the collar **V1**, **Fig. 38** is in line with the timing mark **W1**, **Fig. 38** on the feed lifting connection. The needle bar and hook are timed as described on **Pages 23** and **25**.

TO ADJUST THE THREAD TAKE-UP SPRING AND PULL-OFF

The horizontal portion of the thread pull-off, **L**, **Fig. 23**, should be set about $\frac{1}{32}$ inch below the bottom of the set screw, **K**, **Fig. 23**, when the presser foot is raised by the presser bar lifter. The pull-off can be raised or lowered after loosening the set screw **J**.




Fig. 23. Take-Up Spring Adjustments

The take-up spring should have just enough movement so that it will be through acting and will rest against the upper end of spring regulator **M** when the eye of the needle is about $\frac{1}{16}$ inch above the goods on the downward stroke of the needle. After loosening the set screw **K**, the tension will turn with the stud **N** and the spring regulator may be turned to the required position.

The tension on the thread take-up spring **O** is regulated by turning the tension stud **N** to the right to increase the tension, or to the left to decrease the tension. The tension on the thread take-up spring should be just sufficient to take up the slack of the needle thread until the eye of the needle reaches the goods in its descent.

The above instructions apply to average operation. Adjustments in both setting and tension may have to be made to suit special conditions.




Fig. 24
X-Ray View of 400w21 Machine
(Lubrication Points Shown in Solid Black)

PRESSER BAR ADJUSTMENTS

The presser bar bushing **T**, **Fig. 25** should be set so that its top is about $1/32$ inch below the top of the lifting bracket **S** when the bracket is all the way down.

The presser bar position guide **U** should be set about $1/16$ inch above the top of the lifting bracket **S** when the presser foot is down on the throat plate. The spring between the guide **U** and the bracket **S** cushions the action of the lifting bracket.

To align the presser foot with the needle, have the presser foot down on the throat plate, hold the presser bar position guide **JJ**, **Fig. 23** from slipping either up or down, loosen screw **U2**, **Fig. 25**, move the presser foot to the desired position and re-tighten the screw.

With the feed dog and presser foot down, there should be a slight free motion in the hand lifter lever so that the presser foot will rest on the work during operation of the machine.




Fig. 25. Face Plate Removed

ADJUSTMENT OF THE TENSION RELEASER

The tension releaser **R**, **Fig. 25** automatically releases the spring pressure on the tension discs when the presser bar is raised. The releaser may be moved up or down to release the tension earlier or later, by loosening the screw **Q**.

When stitching on heavy material, the releaser should be set lower than when on light work to prevent stitching with a released tension while sewing heavy material.

TO SET THE NEEDLE BAR AT THE CORRECT HEIGHT

When the needle bar is at its highest position, the lower timing mark **B1**, **Fig. 26** on the needle bar should be just visible at the lower end of the needle bar bushing **W**, **Fig. 26**. If the needle bar is not correctly set, loosen the screw **V**, **Fig. 26** in the needle bar connecting stud and move the needle bar to the correct position.




Fig. 26. Setting Needle Bar

TO SET NEEDLE BAR AT THE CORRECT HEIGHT IF NEEDLE BAR BUSHING SETTING HAS BEEN DISTURBED

Set the needle bar when at the **bottom** of its stroke so that the eye of the needle is above the needle guard of the bobbin case holder just enough to allow freedom for the thread, as shown in **Fig. 29**. Then with the needle at its highest position, the bushing can be reset by driving it so that the lower timing mark **B1**, **Fig. 26** on the needle bar is just visible at the lower end of the bushing.




Fig. 27
Needle Too Low When
at Bottom Stroke




Fig. 28
Needle Too High When
At Bottom of Stroke




Fig. 29
Correct Height of Needle
When at Bottom of Stroke

Turn the machine pulley in the normal direction of rotation to cause the needle to rise .085" (approximately 1/12 of an inch) from its lowest position. In this position, the hook timing mark (Φ) on the large take-up will be in line with the mark **GG**, **Fig. 22** on the face plate. Then set the hook so that its point is at the center of the needle and positioned as described on **Page 25**.

TIMING THE SEWING HOOK

First see that the needle bar is correctly set as instructed on **Page 23**. Remove presser foot, slide plate, throat plate, bobbin case, feed dog and bobbin case holder position finger. Rotate the bobbin case holder about one-half turn so that it is clear of the needle.

To determine whether the hook is correctly timed, place a new needle in the machine, then turn the top of the machine pulley over from you until the needle bar has started to rise from its lowest position and the upper timing mark **A1**, **Fig. 26**, is just visible at the lower end of the




Fig. 30. Timing Sewing Hook

needle bar bushing **W**, **Fig. 26**. In this position, the hook timing mark (Φ) on the large take-up will be in line with the mark **GG**, **Fig. 22** on the face plate. With the needle bar in this position, the point of the sewing hook should be at the center of the needle as shown at **C1**, **Fig. 30** and in the inset.

If the hook time is incorrect, loosen the two screws **H1**, **Fig. 35** in the hub of the hook and turn the hook on its shaft to bring into correct timing.

The point of the hook should pass the needle as closely as possible without actually touching it. This is equal to about the thickness of a piece of ordinary note paper. The hook should be placed on the shaft as far as it will go. If it is necessary to move the hook sidewise, loosen the set screw **J1**, **Fig. 35**, and move the bushing **K1**, **Fig. 35**, with the hook assembly as required, tapping it to the right or prying it to the left with a screw driver against the bed casting.

TO DETERMINE CORRECT RELATIONSHIP OF NEEDLE GUARD TO NEEDLE

The function of the needle guard **Fig. 31** of the bobbin case holder is to prevent the hook point from coming into contact with the needle at loop-taking time in case the needle is deflected sidwise toward the hook point. (However, it will, at this time, cause little or no deflection of the needle, as shown in **Fig. 31**). When the needle guard is correctly related to the needle, it will deflect the needle slightly to the left as the needle approaches its lowest position.




Fig. 31. Showing Correct Relationship of Needle Guard and Sewing Hook Point to Needle at Loop-taking Time

It will sometimes be necessary to string the needle guard, as shown in **Fig. 33**, to provide additional clearance for the needle. Before doing this, the machine should be properly adjusted as previously described. Check the settings in the following order:

1. See that needle bar is set at correct height. See **Page 23**.
2. Make sure that sewing hook is accurately timed. See **Page 25**.
3. See that clearance between sewing hook point and needle is correct. See **Page 25**.
4. Rotate bobbin case holder to its normal position and replace position finger.
5. Check position of bobbin case holder position finger **Fig. 32**. The clearance between position finger and bobbin case holder should be just sufficient to allow thickness of thread to pass through easily. Normal setting is for approximately .020 inch clearance, as shown in **Fig. 32**. The finger should also be level with top of bobbin case holder.




Fig. 32. Showing Thread Clearance Between Bobbin Case Holder Position Finger and Bobbin Case Holder

When it is necessary to provide more clearance for needle, remove bobbin case holder from hook and remove a slight amount of metal from needle guard, by using a $1/8$ inch strip of very fine emery cloth (about #320), holding one end of the emery cloth in a vise and rubbing the edge of the needle guard along the strip, as shown in **Fig. 33**. Extreme care must




Fig. 33. Stringing Needle Guard of Bobbin Case Holder




Fig. 34. Showing Needle Striking Bobbin Due to Removal of Too Much Metal from Needle Guard

be taken not to remove too much metal, as this will allow the hook point to rub the needle, causing wear or damage and thus necessitate replacing the hook and the bobbin case holder. Removing too much metal from guard can expose bobbin, permitting needle to strike it, as shown in **Fig. 34**, and become damaged or broken and to also damage bobbin. Be sure to clean bobbin case holder thoroughly before replacing it.

TO REMOVE AND REPLACE THE SEWING HOOK

Remove the needle, slide plate and bobbin case. Take out the screw **F1**, **Fig. 35** and remove the bobbin case holder position bracket **G1**. Loosen the two set screws at **H1** in the hub of the hook, then turn the machine pulley over from you until the feed bar **AA**, **Fig. 36** is raised to its highest point. Turn the sewing hook until the thread guard **DD** is at the bottom, as shown in **Fig. 36**, and turn the bobbin case holder **BB** until it is in the position shown in **Fig. 36**. The sewing hook can then be removed from the hook shaft.




Fig. 35. Removing Hook

When placing a new sewing hook on the shaft, have the thread guard **DD** of the hook at the bottom and the bobbin case holder **BB** turned to the position shown in **Fig. 36**, so that the hook will clear the feed bar **AA**. Press the hook on the shaft up tightly against the shoulder.

When the hook is in position on the shaft, turn the bobbin case holder **BB** until the notch **CC** is at the top, then replace the bobbin case holder position bracket, being careful to see that the lug **G1**, **Fig. 35**, enters the notch at the top of the bobbin case holder, as shown in **Fig. 35**,

then securely fasten the position bracket by means of the screw **F1**. Replace the needle and time the sewing hook as instructed on **Page 25**. Replace the bobbin case and slide plate.




Fig. 36. Showing Correct Position of Thread Guard (DD) and Bobbin Case Holder (BB) for Removal of Sewing Hook

TO REMOVE THE SEWING HOOK SHAFT

Remove the sewing hook as instructed on **Page 28**. Loosen the pinch screw in the feed lifting rock shaft crank **N1**, **Fig. 38** and drop the feed bar **AA**, **Fig. 36** down and out of the way. Loosen the bushing set screw **J1**, **Fig. 35**, and withdraw the bushing and hook shaft assembly as shown in **Fig. 37**. Take out the two screws **H2**, **Fig. 37** and remove the end bearing **G2**, **Fig. 37**; then withdraw the shaft and gear.

When assembling the hook shaft bushing, see that the thrust washer on the hook shaft has its small end toward the gear. The end bearing **G2**, **Fig. 37** can be moved endwise enough to control the end play of the hook shaft before tightening the two screws **H2**, **Fig. 37**. When replacing this unit in the machine, be sure that the set screw enters the spline in the bottom of the bushing. See **Page 31** when resetting the feed lifting rock shaft.

TO ADJUST ROTATING HOOK SHAFT BUSHING (Pressure Lubricating Type)

The hook shaft bushing contains a regulating screw **V2**, Fig. 37 for controlling the oil supplied to the sewing hook raceway. Turning in the screw **V2** increases the amount of oil supplied to the hook; backing this




Fig. 37. Adjustment of Oil Flow Regulator
in Hook Shaft Bushing

screw out decreases the amount supplied. Normal adjustment is accomplished by turning this screw in all the way, then backing it out again about 2-1/2 turns. Less than 2-1/2 turns may be required if continuous runs are being made or material with considerable sizing is being stitched.

The oil wick complete No. 270176, **W2**, Fig. 37, carried by the hook shaft, at the sewing hook end, should be replaced occasionally, as it may become clogged by lint and dirt from the oil.

If an excess of oil is being delivered to the hook and cannot be controlled by the metering screw **V2**, Fig. 37, check to be sure that the oil wick has not become detached from the filter screw **W2**, Fig. 37 and that the filter screw is securely tightened. Inspect all oil passages in the shaft and bushing to see that they have not become clogged with lint or dirt. If oil wick is too loose, too much oil will flow to the hook raceway.

To test for delivery of oil to the hook, run the machine at normal speed for one minute to remove any excess of oil and to establish a uniform rate of flow. Without stopping the machine, hold a small piece of white paper underneath the hook for 15 seconds without moving the paper during the interval. Remove the paper and inspect. If the paper does not show an oil streak about 1/32 inch wide, insufficient oil is being delivered to the hook. The most efficient method of testing oil delivery to hook is to remove hook and hold paper under end of hook shaft with machine running at full speed for 15 seconds; the oil streak should then be about 1/16 inch wide.

TO REMOVE AND REPLACE THE HOOK DRIVING SHAFT

Slip the belt off the lower pulley **Y1**, Fig. 38, then loosen the two set screws **X1**, Fig. 38 and remove the pulley from the shaft. Loosen the four set screws **U1** and **P1**, Fig. 38 in the feed driving and feed lifting eccentrics, and the two set screws at **R1**, Fig. 38 in the internal gear. Do not loosen the screw in the collar **V1**, Fig. 38. Withdraw the shaft with ball bearing from the pulley end.

When replacing the shaft, push it in, being sure the feed eccentrics are on the shaft in their proper order, until the snap ring on the ball bearing seats on the casting, then tighten gear screws **R1**. Before tightening the screws **U1**, the feed eccentric should be pushed to the left as far as it will go.

Tighten the screws **U1**, Fig. 38, having the first screw (as the shaft is turned away from you) enter the groove in the shaft. Then move the feed lifting eccentric to the left as far as it will go and tighten the screws **P1**, with the first or upper set screw in the groove in the shaft. Replace pulley **Y1** and belt. Then retime the shaft as instructed on Page 18.

If it is found necessary to replace the ball bearing on the hook driving shaft, or to reset or replace the hook driving shaft bushing, note that the ball bearing is correctly positioned when the pulley **Y1**, Fig. 38 is flush with the ball bearing on one side and its hub is flush with the end of the shaft on the other. With the ball bearing in this position, place the




Fig. 38. Underside of Machine 400w21

shaft in the machine and assemble the internal gear **Z1**, Fig. 38 with its inner face flush with the end of the shaft. The hook driving shaft bushing will be correctly positioned when end play has been removed from the shaft by setting the bushing against the hub of the internal gear.

If the feed rock shafts have been disturbed, the small ends of the connections **O1** and **T1**, Fig. 38 should be disconnected while setting the eccentrics, and enough side play left for the connections so that their free ends can be moved sidewise about 1/32" to 1/16". See paragraph on feed mechanism on Page 32 before assembling the rock shaft connections.

FEED MECHANISM

If a faster or slower feed timing than the standard setting is desired, see **Page 18**; loosen the pulley screws **X1**, **Fig. 38** and turn the shaft as desired, then tighten the screws. The hook must then be re-timed as instructed on **Page 25**.

The feed dog is lined up with the slots in the throat plate by moving the bearing centers at **Q1**, **Fig. 38** to right or left. It may be centered lengthwise so it will not strike the ends of the slots when making the longest stitch, by loosening the clamp screw in the feed rock shaft crank **S1**, **Fig. 38**.

After removing the feed driving or feed lifting rock shafts, the cranks **S1** or **N1**, **Fig. 38** should be adjusted to right or left until they line up perfectly with the free ends of the connections when the latter are exactly midway between their two extreme side play positions. The cone bearings **O1** and **T1**, **Fig. 38** should then be adjusted by first turning the cone screws down tight and then backing them off one-quarter of a turn, locking them in position with the lock nut. This gives a perceptible amount of play in the connection which is necessary for all clearance.

SETTING THE FEED DOG AT THE CORRECT HEIGHT

The feed dog may be raised or lowered by loosening the pinch screw in the feed lifting crank **N1**, **Fig. 38**. The feed dog is usually set so that it shows a full tooth above the throat plate when at its highest position. See that there is no lint packed between the feed dog and throat plate.

ADJUSTING FEED ECCENTRIC ON MACHINES




Fig. 39. Feed Eccentric

A spring held by the collar **V1** presses against the feed eccentric cam to prevent it from moving out of position while the machine is operating. The collar **V1** should ordinarily be set flush with the end of the hub of the eccentric body. The set screw in this collar must enter the timing groove in the eccentric body.

The feed eccentric is provided with a gib **L2**, **Fig. 39**, which can be adjusted to take up any loose motion between the feed eccentric and the eccentric body. To adjust the gib, loosen the two locking screws **K2** nearest the gib, then turn in the two adjusting screws **J2** against the gib until all play is eliminated and the eccentric fits snugly in the slot in the eccentric body. Securely tighten the two locking screws **K2**. By tightening the adjusting screws **J2** firmly, the eccentric will be locked so that the stitch length cannot be changed by unauthorized persons.

TO REMOVE AND REPLACE THE ARM SHAFT CONNECTION BELT

Remove the needle to avoid damaging it while the arm and hook shafts are out of time. Work the belt off the lower pulley **Y1**, **Fig. 38**.

Loosen the two screws in the pulley groove and remove the machine pulley and the ball bearing which comes out with the pulley. Lift the belt up and draw it out around the arm shaft through the space normally occupied by the ball bearing.

Replace the belt through the ball bearing hole. After placing the belt over the upper pulley **M2**, **Fig. 40**, replace the machine pulley. To remove all end play from the shaft, lightly tighten the set screws in the machine pulley and, holding the needle bar crank in place, tap the machine pulley into position with the palm of the hand; then tighten screws firmly. Turn the arm shaft until the arrow **G**, **Fig. 22** on the take-up disc is in line with its timing mark **GG**, **Fig. 22**, and turn the lower pulley until the timing mark on the collar **V1**, **Fig. 38**, is opposite the mark **W1**, **Fig. 38**, being careful to see that the two set screws **X1**, **Fig. 38** are accessible. With the two shafts in this position, lead the belt onto the lower pulley at the point farthest from you and then, while turning the machine pulley over from you, slide the belt over the rest of the width of the lower pulley. Check the timing of the machine before starting to sew; see **Page 18**, and if necessary, loosen the set screws in the lower pulley to bring the upper and lower shafts into exact time.

TO REMOVE AND REPLACE THE SMALL TAKE-UP SHAFT CONNECTION BELT




Fig. 40. Rear Arm Cover Removed

Remove the arm shaft connection belt as instructed above, then slip the take-up belt **O2**, **Fig. 40** off the pulleys, being careful not to place too much sidewise strain on the arm shaft while it is unsupported by the rear bearing. When replacing the belt, have the arrows **G** and **X**, **Fig. 22** on both take-up discs in line with their respective timing marks **GG** and **XX** as shown in **Fig. 22**. Replace the small belt **O2**, **Fig. 40** on both pulleys, then replace the long belt as instructed above.

TO REMOVE AND REPLACE THE SMALL TAKE-UP SHAFT

The small take-up shaft must be removed from the pulley end of the machine. Remove the take-up belt **O2, Fig. 40** as instructed on **Page 33**, or by loosening the two set screws in the small pulley and slipping the pulley off the shaft while turning the machine pulley. Remove the take-up guard **C2, Fig. 22** and loosen the set screw, through the hole **7, Fig. 22** in the top of the arm, which holds the small take-up disc. Remove the shaft with the rear ball bearing through the pulley end of the machine.

The front and rear ball bearings for replacement on the small take-up shaft will be a tight fit. The front ball bearing should be placed on the shaft before it is assembled in the machine and the face plate **D2, Fig. 22** should be removed from the machine. To obtain the correct position, force the bearing on the shaft until flush with the hub of the small rotary take-up and after placing the shaft in the machine with the snap ring of the front ball bearing against its seat, force the rear ball bearing on until all end play has been eliminated.

When replacing the belt **O2** and the small belt pulley, make certain that the set screws in the small pulley are accessible when the take-up discs are at their timing positions.

TO REMOVE THE ARM SHAFT

The arm shaft must be removed from the face plate end of the machine and under no circumstances should an attempt be made to separate the needle bar crank from the shaft, as they are manufactured as a unit for accuracy. Remove face plate **D2, Fig. 22** and associated parts. Remove the needle set screw. Loosen the needle bar pinch screw **V, Fig. 25**, remove the needle bar through the top of the arm, and remove the needle bar connecting stud. Remove the needle bar crank stud **P2, Fig. 25** by loosening the two set screws, reached through hole **E2, Fig. 22** in the top of the arm. To remove the needle bar connecting link, drop it to its lowest position, draw forward out of the guide block, turn at right angles, then draw upward and outward. (If for any reason the needle bar guide block is disturbed, it must be aligned properly when assembling the machine). Remove the belts as instructed in the preceding paragraphs, loosen the spot screw and set screw in pulley **M2, Fig. 40** and withdraw the arm shaft and crank from the needle bar end. If it is found necessary to replace the ball bearing, it should be forced onto the shaft until the slip ring is flush with the needle bar crank.

INSTRUCTIONS ON BALL BEARINGS AND NEEDLE BEARINGS

There are five ball bearings and three needle bearings in these machines that will give long, trouble-free life with reasonable care. Oiling instructions given on **Pages 5 to 7** should be followed carefully. Care should be taken to see that no foreign matter gets into these bearings when handling them out of the machine.

The ball bearings on the forward end of the arm shaft, the rear end of the small take-up driving shaft, and the rear end of the hook driving shaft are forced on into their correct position at the factory and should not be removed except for replacement. When replacing them, make certain that the shielded side is always out and that they are a tight fit on their respective shafts.

The ball bearing on the machine pulley is also a forced fit. Tools for removing the machine pulley from the machine and for removing this bearing can be procured from the SINGER Agencies if needed.

The three needle bearings should receive the same care as the ball bearings and should not be removed from their respective housings except for replacement. They should be replaced by pressing on the numbered end of the outside shell, as any pressure on the unnumbered end of the shell will distort them and cramp the bearings. After this, care should be taken to see that the needle bearings roll freely in their respective housings.