

PARTS LIST

Model 206RBATC

Model 206RBATCL






Fig. 1





30102 - DC 24V
30104 - DC 40V







Fig. 4


PC24V-18A01
DC40V-18A02











RE. 6








18380




6057




10734




d054



8132




18358




6332

300120




1832A

1834 A




1808 A

10748




15571




10747

11969





30194



605 2



6051




8123







8121



8120



8118



10780

R. 9