



1293

Unterklassen-Ausstattung

Subclass parts

Composition des sous-classes

Composición de las subclases


Unterklassen-Ausstattung
Subclass organizations

Equipement des sous-classes
Dotación de las subclases

Unterklasse Subclass Sous-classe Subclase	Ausführung Model Version Tipo de máquina	Nadelstange Needle bar Barre à aiguille Barra de aguja	Stoffschieber Feed dog Griffe Transportador	Stichplatte Needle plate Plaque à aiguille Placa de aguja	Nähfuß Presser foot Pied presseur Pie prensatelas	Fingerschutz Finger guard Protège-douglis Salvadedos
-750/01-4/01	CN; DN	91-009 678-91	91-045 599-04	91-048 321-04	91-141 232-13	91-012 658-91
-750/01-4/01-900/56	CN; C/DN	91-009 678-91	91-059 186-04	91-158 087-04	91-141 232-13	91-012 658-91
-944/01	CN; DN	91-009 678-91	91-045 599-04	91-048 321-04	91-051 255-93	91-157 813-91
-944/01-900/56	CN; C/DN	91-009 678-91	91-059 186-04	91-158 087-04	91-051 255-93	91-157 813-91

4 = Ausführung angeben
 = Indicate model
 = Préciser la version
 = Indíquese el tipo de máquina

Unterklassen-Übersicht/ Table of subclasses/ Table des sous-classes/ Tabla de subclases



Pfaff, D 6750 Kaiserslautern, Postfach 3020/3040, Telefon (0631) 200-0, Telex: 45753, Telefax (0631) 17202