SINGER*

Operator's Guide

108U 30


* A Trademark of THE SINGER COMPANY Copyright © 1985 THE SINGER COMPANY All Rights Reserved throughout The World

BRIEF DESCRIPTION

Single needle, lockstitch machines featuring a unique "walking foot" (Unison Feed) mechanism and cylinder bed.

APPLICATION

Binding knit gloves, mattresses, sandals, shoe tongues, button straps, dress shields, shoe uppers, canvas shoes, etc.




SPECIFICATIONS

	108U20	108U30
Vibrating and Lifting Presser Foot Lift	0.10'' (2.5mm)	0.14" (3.5 mm)
Bed Dimension at End of Cylinder	1-13/16'' (46.0 mm)	
Space at Right of Needle	5-3/4" (146.0 mm)	
Clearance under Presser Foot	7/32" (5.6mm)	
Max. Stitch Length	8 S.P.I. (3.2 mm)	
Max. Speed (RPM)	2,700	2,100
Needle	Cat. 1451 (135X1)	
Binder (Attached)	Part No. 224710, 0.025-7/16" (standard)	
Binder Tape Guide (Attached)	Part No. 208329, 7/16" (standard)	


NEEDLE

Use Singer needle Catalog 1451 (135X1)




THREADING NEEDLE


Thread only with the needle bar in highest position.




BOBBIN REMOVAL




BOBBIN WINDER




REPLACEMENT AND THREADING BOBBIN






Draw thread up and over bobbin case toward the back of the machine.



Draw up needle thread and bobbin thread will come up.

STITCHING MARGIN


After stitching margin is adjusted, two screws should be tighten firmly.




THREAD TENSION

Tension on threads should be as light as possible, while still sufficient to set stitch correctly in material.

Bobbin Thread



Needle Thread




Regulate needle thread tension only when presser feet are down.

STITCH LENGTH REGULATION

LENGTHEN THE STITCH SHORTEN THE STITCH

Turn regulating dial to desired stitch length.

PRESSER FOOT PRESSURE





The pressure on material should be as light as possible while still sufficient to insure proper feeding.


LUBRICATION

Twice Daily (Mote frequently with severe use)

Use SINGER "TYPE B" or "TYPE D" OIL.







Form U3560 (385) Part No. 409882-002 Printed in Japan

:

ENGTHEN HE STITCH

ORTEN E STITCH